ChronoTrack D-Tag Instructions



Remove D-Tag and

directions from race bib



Fold along perforation and tear D-Tag from directions



Crease D-Tag along fold lines



Slide D-Tag under single lace cross face down



Remove paper tab under marked black area



Overlap and align clip holes forming a loop, press firmly to adhere



If provided, attach
D-Tag clip through hole
and snap together



Rotate D-Tag number side up, black marking down

Visit
chronotrack.com
for more
information
on the
ChronoTrack
D-Tag